TROY-BILT®

Parts Catalog

Suburban Tractor

Models

13064

130640100101 through
130640199999

13065

130650100101 through
130650199999

13066

130660100101 through
130660199999

© GARDEN WAY, 1993

FORM 1 767542 (4/93)



BODY WORK AND TRIM ASSEMBLY

Ref #	Part #	Description	Qty.
1	1756861	Seat (C)	1
†	1757363	Seat (A) (B)	1
2	1186347	Fl. Screw 3/8-16 x 1	2
3	1755790	Plug	1
4	1732499	Toplock Nut, 5/16-18	2
5	1713233	Flat Washer, 1-1/2 (A) (B)	2
6	1107383	Flat Washer, 3/8	2
7	1734269	Knob	2
8	1764659	Upper Foam (A) (B)	1
9	1737951	Self Thd. Nut	2
11	1761031010	Rear Fender	1
12	1759101	Decal, Hood–Front	1
13	1759100	Decal, Hood	2
15	1759104	Decal, Fender R.H. (B)	1
	1757944	Decal, Fender R.H. (A)	1
	1763857	Decal, Fender R.H. (C)	1
16	1759103	Decal, Fender L.H. (B)	1
	1757945	Decal, Fender L.H. (A)	1
	1763858	Decal, Fender L.H. (C)	1
17	1186391	Fl. Nut, 5/16-18	13
18	1893445	Washer	2
20	1743987010	Running Board Support	1
21	1751805010	Running Board, R.H.	1
22	1751803010	Running Board, L.H.	1
23	1742665	Foot Pad, R.H.	1
24	1755729	Foot Pad, L.H.	1
25	1186330	Fl. Lock Screw, 5/16-18 x 7/8	11
26	1755944	Center Foot Pad	1
27	1764351	Decal, Instruction	1
29	1755933	Decal, Choke (C)	1
	1761578	Decal, Choke (A) (B)	1
30	1111599	Hex Hd. Screw, 1/4-20 x 5/8	4
31	1758070	Hex Hd. Screw, #10-24 x 5/8	2
32	1762861	Hinge Link, RH	1
33	1764587010	Hinge Strap Ass'y	2
35	1764360	Top Lock Nut 1/4-20	8
36	1763048	Hinge Link, LH	1
37	1186309	Fl. Lock Screw, 1/4-20 x 5/8	12
38	1186389	Fl. Lock Nut, 1/4-20	12
39	1186308	Fl. Lock Screw, 1/4-20 x 1/2	2
41	1762875	Grille	1
44	1762858010	Side Cover, L.H.	1
45	1762859010	Side Cover, R.H.	1
47	1727127	Rubber Latch	2
48	1727126	Clip	2
49	1185985	Keps Nut, #10-24	2
50	1764657	Rod-Hood	2
52	1762856010	Hood Ass'y	1
53	1756876	Decal, Service Instructions	1
55	1107381	Flat Washer, 1/4	4
56	1753039	Instrument Panel	1
57	1755931	Decal, Throttle	1
58	1756739	Cap (C)	1
59	1755932	Decal, Ignition	1
61	1758766	Sealing Block (A) (B)	4
65	1757366	Decal, Fuel	1
67	1186469	Carriage. Bolt 5/16-18 x 5/8	2
68	1186393	Fl. Nut, 3/8-16	2
69	1701055	Flat Washer	2
70	1755449	Comp. Spring	2
71	1759102	Decal, Rear Fender	1
72	1706782	Wave Washer	2
73	1705793	Nylon Washer	2
74	1754125	Shoulder Bolt	2
75	1760963001	Seat Support Ass'y	1
77	1753911	Pivot Block	1
78	1757939	Decal, Side Cover L.H.	1
	1757938	Decal, Side Cover R.H.	1
79	1900333	Decal, Made in USA	1
80	1723384	Washer	2
81	1100799	Hex Hd. Screw, 5/16-18 x 1-1/2	2
83	1764597001	Support Assembly, LH	1
84	1764598001	Support Assembly, RH	1
85	1757542	Clip	4

(A) Model 13065--Serial Numbers 130650100101–130650199999
(B) Model 13066--Serial Numbers 130660100101–130660199999
(C) Model 13064--Serial Numbers 130640100101–130640199999

† Deluxe Seat, fits all units.

SUBURBAN TRACTOR

S/N 130640100101-130640199999
S/N 130650100101-130650199999
S/N 130660100101-130660199999



FRAME, LIFT AND STEERING ASSEMBLY

Ref #	Part #	Description	Qty.
2	1747804	Steering Wheel (A) (C)	1
	1753279	Steering Wheel (B)	1
3	1185279	Roll Pin, 1/4 x 2-1/4 (A) (C)	1
	1185533	Roll Pin, 1/4 x 1-1/2 (B)	1
4	1185632	Flange Bearing	1
5	1752363	Steering Shaft Support	1
6	1186389	Fl. Nut, 1/4-20	9
7	1186309	Fl. Screw, 1/4-20 x 5/8	13
8	1758797010	Instrument Panel Support (A) (B)	1
	1758724010	Instrument Panel Support (C)	1
9	1185456	U-Type Speed Nut, 1/4-20	4
10	1756073001	Battery Support	1
11	1757291	Belt Guide	2
12	1703539	Handle Grip	1
13	1759450001	Lift Lever Ass'y	1
14	1186330	Fl. Lock Screw, 5/16-18 x 7/8	31
15	1750957	Jam Lock Nut, 1/2-20	2
16	1750581	Steering Arm	1
17	1805368	Washer	1
18	1185427	Retaining Ring	2
19	1747189	Pin	1
20	1754179	Push Link	1
21	1757661	Stationary Guide	1
22	1107385	Flat Washer, 1/2	2
23	1186391	Fl. Lock Nut, 5/16-18	41
24	1100350	Cotter Pin, 1/8 x 1	2
25	1751070	Lift Rod	1
27	1754950001	Lift Shaft Assembly	1
28	1754944001	Fender Support Assembly	1
29	1758842001	Rear Panel Ass'y	1
30	1740984001	Axle Support	2
31	1757659	Sliding Guide	1
33	1177567	Retaining Ring	2
34	1755847001	Rear Frame	1
35	1742934	Angle Bracket Speed Nut	4
36	1751284	Steering Shaft	1
37	1730375	Shim Washer	A/R
38	1747303	Flange Bearing	1
39	1750594	Steering Support Ass'y	1
40	1715301	Thrust Washer	1
41	1750501	Sector Gear Ass'y	1
42	1185386	Flange Bearing	2
43	1113527	Retaining Ring	1
45	1750495	Spindle Arm Ass'y	1
46	1100049	Hex Hd. Screw, 3/8-16 x 2-1/4	2
47	1733398	Hex Lock Nut, 3/8-16	4
48	1708755	Flat Washer, 3/8	4
49	1110150	Lock Nut, 3/8-24	2
50	1716180	Ball Joint	2
51	1186247	Jam Hex Nut, 1/2-20	2
52	1750499001	Steering Rod	1
53	1185803	Grease Fitting	1
54	1763859001	Attachment Bracket	1
55	1186345	Fl.Hex Screw, 3/8-16 x 3/4	4
56	1186393	Fl. Hex Nut, 3/18-16	4
57	1758231	Hex Lock Nut, 5/8-11	1
58	1758232	Hex Hd. Screw, 5/8-11 x 2-1/2	1
59	1750486001	Spindle Ass'y, L.H.	1
60	1750490001	Spindle Ass'y, R. H.	1
61	1750341	Bushing	4
62	1718086	Valve Stem	2
63	1185976	Grease Fitting	4
64	1757981	Wheel (Incl. Refs. 61 & 63)	2
65	1762254	Tire, 15 x 6.00-6RS	2
66	1742133	Flange Bearing	4
67	1185388	Retaining Ring	4
68	1701447	Washer	A/R
69	1750494001	Front Axle Ass'y	1
70	1750841001	Tie Rod	1
71	1742343001	Front Frame	1
72	1744320	Belt Guide	1
73	1764776	Dust Cap	2
74	1185830	Special Washer	A/R
75	1747320	Cable Guide	1
76	1100043	Hex Screw, 3/8-16 x 1-1/4	2
77	1756177	Pulley	2
78	1747322	Spacer	2
79	1747316001	Bracket	1
80	1747315001	Bracket	1
82	1185388	Retaining Ring	2
83	1751715001	Bracket	2

(A) Model 13065--Serial Numbers 130650100101–130650199999
(B) Model 13066--Serial Numbers 130660100101–130660199999
(C) Model 13064--Serial Numbers 130640100101–130640199999



Torque to 30-35 Ft.–Lbs.

ENGINE ASSEMBLY

Ref #	Part #	Description	Qty.
1	1744390	Fuel Tank Pad	1
2	1186329	Fl. Screw, 5/16-18 x 3/4	2
3	1758459001	Heat Shield	2
4	1762101	Fuel Line	1
5	1750687	Hose Clamp	3
6	1751477	Elbow, 90°	1
7	1738433	Bushing	1
8	1737118	Knob	2
9	1758801	Throttle Control	1
10	1758800	Choke Control	1
11	1115815	Phil. Hd. Screw, #10-24 x 5/8	4
12	1185985	Keps Nut #10-24	4
13	1758426001	Heat Shield	1
14	1727491	Fuel Filter	1
15	1764658	Foam, Lower	1
16	*	Engine, Briggs & Stratton 14 HP Model 294777 (13014) (13015)	1
	*	Engine, Briggs & Stratton 16 HP Model 303777 (13016)	1
17	1186230	Hex Nut, 5/16-18	6
18	1100242	Lock Washer, 5/16	4
19	1758311001	Bracket	1
20	1735531	Cable Tie	4
21	1747738	J-Clip	3
22	1745366	Cable Hanger	3
23	1758458	Oil Drain Tube	1
24	1745688	Pipe Cap	1
25	1105029	90° Elbow	1
26	1744455	Special Washer, 7/16	1
27	1100244	Lock Washer, 7/16	1
28	1758464001	Heat Shield	1
29	1767165	Hex Screw, 7/16-20 x 3	1
30	1185986	Speed Nut, #10-24	4
31	1763649001	Heat Shield	1
33	1111606	Screw, 5/16-18 x 2	1
34	1100799	Hex Hd.. Screw, 5/16-18 x 1-1/2	3
35	1748146	Sq. Key, 1/4 x 1-1/2	1
36	1742535	Sheave	1
37	1755341	Electric Clutch	1
38	1754787	Clutch Retainer	1
39	1100255	Flat Washer, 5/16	1
42	1758719	Spacer	3
43	1763650	Muffler	1
44	1758940	Muffler Deflector	1
45	1748758	Fuel Gauge	1
46	1756460	Fuel Tank (Incl. Refs. 6, 7 & 45)	1
47	1750962	Screw, #10-24 x 5/8	2
48	1714721	Spacer	1
49	1100069	Hex Hd. Screw, 1/4-20 x 1	4
50	1758768	Sealing Strip	1
51	1100241	Lock Washer, 1/4	4
52	*	Gasket	2

* Engine warranty service and repair parts are available from your local authorized Briggs and Stratton dealer. Refer to the engine for its model, type number and code number.



ENGINE ASSEMBLY

Ref #	Part #	Description	Qty.
1	1744390	Fuel Tank Pad	1
2	1748757	Fuel Tank Guage	1
3	1756460	Fuel Tank (Incl. Ref. 2)	1
4	1752795	Fuel Line	1
5	1750687	Hose Clamp	3
8	1737118	Knob	2
9	1755926	Throttle Control	1
10	1755927	Choke Control	1
12	1185985	Keps Nut, #10-24	4
14	1727491	Fuel Filter	1
16	*	Engine, Kohler Model CV12.59 (OHV) 12.5 HP	1
19	1763988	Hex Screw, M10 x 1.25 x 80	1
20	1735531	Cable Tie	5
21	1747738	J-Clip	3
26	1744455	Special Washer	1
27	1100244	Lock Washer, 7/16	1
31	1763875	Fl. Screw, Thd. Form. 1/4-20 x 3/8	2
32	1763862	Engine Harness	1
33	1860219	Hex Hd. Screw, M8 x 1.25 x 35	1
34	1100242	Lockwasher, 5/16	1
35	1748146	Sq. Key, 1/4 x 2-1/2	1
36	1742535	Sheave	1
37	1755341	Electric Clutch	1
38	1754787	Clutch Retainer	1
39	1100255	Flat Washer, 5/16	2
45	1750962	Screw, #10-24 x 5/8	4
46	1764845001	Heat Shield	1
47	1763852	Muffler	1
48	1860217	Hex Screw M8 x 1.25 x 25	3
54	1743683	45° Elbow	1
56	*	Gasket	1
57	1745366	Hangar Cable	1
58	*	Nut, M8 x 1.25	2
59	1763866	Oil Drain Tube	1
60	1745688	Cap	1
61	1186389	Fl. Nut, 1/4-20	1
62	1186309	Fl. Screw, 1/4-20 x 5/8	1
63	1764692001	Support Bracket	1
64	1740083	Clamp	1

* Engine warranty service and repair parts are available from your local authorized Kohler dealer. Refer to the engine for its model, type number and code number.



ELECTRICAL ASSEMBLY

MODELS 13065 & 13066



Ref #	Part #	Description	Qty.
1	1751340	Switch, Cruise Interlock	2
2	1756074	Battery Cable (Pos.)	1
5	1752871	Headlight Ass'y (w/ ref. 48 & 49)	2
6	1749907	Relay	1
7	1765500	Screw, #10-24 x 1-1/2	2
8	1735531	Wire Tie	6
9	1754220	Battery Cable (Neg.)	1
10	1752874	Reflector	1
11	1757364	Hour Meter	1
12	1764803	Block	1
13	1107381	Flat Washer, 1/4	2
14	1734398	Hex Lock Nut, 1/4-20	2
15	1752586	J-Bolt	2
16	1115815	Phil. Hd. Screw, #10-24 x 5/8	2
17	1185985	Nut, #10-24	6
18	1752840	Battery	1
19	1752137	Solenoid	1
20	1750963	Screw, # 6-32 x 1/2	5
22	1186229	Hex Nut, 1/4-20	2
23	1748014	Grommet	1
24	1752841	Starter Cable	1
25	1752134	Console Wiring Harness	1
26	1747738	J-Clip	4
27	1761006	Battery Tray	1

Ref #	Part #	Description	Qty.
28	1100241	Lock Washer	2
29	1111599	Screw, 1/4-20 x 5/8	2
30	1756180	Interlock Harness	1
31	1754608	PTO Switch	1
32	1754856	Light Switch	1
33	1754250	Ignition Switch	1
34	1753986	Ignition Key	1
35	1758466	Engine Harness	1
36	1755802	Cover	1
37	1735285	Bulb	3
38	1186020	Thd. Cut Screw, #6-32 x 3/8	2
39	1743516	Replacement Fuse, 30A	1
40	1756872	Lense	1
41	1752132	Voltage Sensor	1
43	1755349	Pan Hd. Screw, 1/4-20 x 1/2	2
44	1752506	Switch	1
45	1755487	Grommet	1
46	1734934	Grommet	1
47	1751328	Brake Interlock Switch	1
48	1752872	Bulb	2
49	1752875	Socket	2
50	1754607	Cruise Switch	1
54	1764583	Gasket	4



ELECTRICAL ASSEMBLY

MODEL 13064



Ref #	Part #	Description	Qty.
1	1752874	Reflector	2
2	1756074	Battery Cable (Pos.)	1
3	1752872	Bulb	2
4	1752875	Socket	2
5	1752871	Headlight Ass'y (w/ ref. 3 & 4)	2
8	1735531	Wire Tie	6
9	1754220	Battery Cable (Neg.)	1
10	1756872	Lense	1
13	1107381	Flat Washer, 1/4	2
14	1764358	Hex Lock Nut, 1/4-20	2
15	1752586	J-Bolt	2
16	1115815	Phil. Hd. Screw, #10-24 x 5/8	2
17	1185985	Nut, #10-24	2
18	1752840	Battery	1
19	1752137	Solenoid	1
20	1750963	Screw, # 6-32 x 1/2	5
22	1186229	Hex Nut, 1/4-20	2
23	1748014	Grommet	1
24	1741506	Starter Cable	1
25	1752134	Console Wiring Harness	1
26	1747738	J-Clip	4
27	1761006	Battery Tray	1
28	1100241	Lock Washer	2
29	1111599	Screw, 1/4-20 x 5/8	2
30	1756076	Interlock Harness	1
31	1754608	PTO Switch	1
32	1754856	Light Switch	1
33	1754250	Ignition Switch	1
34	1753986	Ignition Key	1
35	1763862	Engine Harness	1
36	1755802	Cover	1
37	1735285	Bulb	3
38	1186020	Thd. Cut Screw, #6-32 x 3/8	2
39	1743516	Replacement Fuse, 30A	1
40	1756739	Plug	1
43	1755349	Pan Hd. Screw, 1/4-20 x 1/2	2
44	1752506	Switch	1
45	1755487	Grommet	1
46	1734934	Grommet	1
47	1751328	Interlock Switch	1
51	1758070	Screw, #10-24 x 5/8	2
53	1764583	Gasket	4

SUBURBAN TRACTOR

S/N 130640100101-130640199999
S/N 130650100101-130650199999
S/N 130660100101-130660199999



Ref #	Part #	Description	Qty.
1	1755883001	Pedal Ass'y	1
2	1753188	Pivot Block	1
3	1185802	Flange Bushing	2
4	1756687001	Hydro Pedal Support	1
5	1107386	Flat Washer, 5/8	1
6	1756166	Control Shaft Ass'y (A) (B)	1
	1755880	Control Shaft Ass'y (C)	1
7	1753190	Torsion Spring	1
8	1120209	Roll Pin, 3/16 x 3/4	2
9	1755878	Control Shaft Ass'y	1
	1755880	Control Shaft Ass'y (13064 only)	1
10	1100049	Hex Hd. Screw, 3/8-16 x 2-1/4	1
11	1107383	Flat Washer, 3/8	13
12	1751597	V-Belt	1
13	1733398	Lock Nut, 3/8-16	4
14	1749904	Special Pivot	1
15	1714233	Snap Bushing	2
16	1746942	Clutch Rod	1
17	1751879	Clutch Arm ass'y	1
18	1760321	Adjusting Screw	1
19	1186247	Jam Nut, 1/2-20	1
20	1751022	Compression Spring	1
21	1764131	Brake Rod	1
22	1120210	Roll Pin, 3/16 x 13/16	4
23	1751880	Arm Assembly	1
24	1751063	Brake Lock Rod	1
25	1755787001	Tank Support	1
26	1111610	Hex Screw, 5/16-18 x 3	4
27	1756049001	Brake Pedal Ass'y	1
28	1100350	Cotter Pin 1/8 x 1	5
29	1728694	Foot Rest	1
30	1100359	Cotter Pin, 1/8 x 5/8	5
31	1751809	Torsion Spring	1
32	1715538	Nylon Bushing	2
33	1746941	Idler Arm Ass'y	1
34	1760096	Belt Guide	2
35	1100086	Hex Screw, 3/8-16 x 1-3/4	1
36	1756151	Idler	1
37	1185759	Roll Pin, 1/4 x 3	1
38	1756144	Latch	1
39	1185879	Pop Rivet	1
40	1186309	Fl. Screw, 1/4-20 x 5/8	3
41	1186389	Fl. Lock Nut, 1/4-20	1
42	1185689	Retaining Ring	2
43	1747872	Washer	A/R
44	1765605	Tire, 20-8.00-10 x 8RS	2
45	1718086	Valve Stem	2
46	1765608	Wheel Disc	2
47	1760193	Hydro Sheave	1
48	1104337	Sq. Key, 1/4 x 1-1/2	2
49	1753186	Adj. Block Ass'y	1
50	1753199	Speed Control Arm Ass'y	1
51	1100905	Woodruff Key, 1/8 x 1/2	1
52	1753193	Pivot Shaft Ass'y	1
54	1185885	Woodruff Key, 3/16 x 5/8	1
55	1120209	Roll Pin, 3/16 X 3/4	1
56	1761608	Flat Washer	1
57	1760370	Fan	1
58	1100069	Hex Screw, 1/4-20 x 1	1
59	1100241	Lock Washer, 1/4	1
60	1753189	Dowel Pin	1
61	1186245	Jam Nut, 3/8-24	1
62	1756175	Ball Joint	1
63	1762704	Brake Arm Ass'y	1
64	1756627	Guide	1
65	1734398	Lock Nut, 1/4-20	2
66	1893445	Washer	1
67	1756181001	Interlock Bracket (13065 & 13066)	1
	1755584001	Interlock Bracket (13064)	1
68	1729482	Extension Spring	1
69	1186327	Fl. Screw, 5/16-18 x 1/2	4
70	1186330	Fl. Screw, 5/16-18 x 7/8	4
71	1186391	Fl. Lock Nut, 5/16-18	4
72	1754946001	Transaxle Brace	1
73	1747186	Push-On Cap	1
74	1751808	Idler Support Ass'y	1
75	1747166	Set Screw	2
76	1763170	Brake Link	1
77	1755929	Belt Guide, R.H.	1
78	1755930	Belt Guide, L.H.	1
79	1100045	Hex Screw, 5/16-18 x 1	2
81	1100255	Flat Washer, 5/16	10
82	1755928	Flange Bearing	2
83	1732499	Lock Nut,5/16-18	4
84	1755939	Jackshaft Ass'y	1
85	1739919	Speed Nut, #10-24	4
86	1115815	Phil. Hd. Screw, #10-24 x 5/8	4
87	1760097	Idler	1
88	1107385	Flat Washer, 1/2	1
89	1713783	Spacer	1
90	1747873	Cap	2
91	1177567	Retaining Ring	2
92	1748491	Pivot Block	1
93	1754948	Fan Shroud	1
94	1100242	Lock Washer, 5/16	2
95	1755822	Fuel Hose	1
96	1756626	Hose Clamp	4
97	1755088	Oil Reservoir Ass'y	1
98	1705093	Washer, 1/32 Thk.	A/R
99	1705092	Washer, 3/32 Thk	A/R
100	1100243	Lock Nut, 3/8	2
101	1701449	Washer	2
102	1762791	Hydrostatic Transaxle, Eaton 751-047 (See Page 20 for Breakdown)	1
103	1755823	Hose	1
104	1186396	Fl. Nut, 7/16-20 (not 13064)	1
105	1754675	Magnet (not 13064)	1
106	1750736	Special Screw (not 13064)	1
107	1761191	Jam Nut, 3/8-24	1
109	1762599	Shaft Support	1

(A) Model 13065--Serial Numbers 130650100101–130650199999
(B) Model 13066--Serial Numbers 130660100101–130660199999
(C) Model 13064--Serial Numbers 130640100101–130640199999


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
39a
40
41
42
43
44
45
46
48
53
54
A
B
C
D
E
F
G
H
I
J
K

Ref #	Part #	Description	Qty.
1		Screw, 1/4-20 Self Tap	13
2		Cover (S/A)	1
3		Ring, Retaining, Internal	1
4	1760892	Shaft, Input (S/A)	1
5	1760893	Seal, Input Shaft	1
6	1757374	Seal, Control Shaft	1
7		Cover	1
8		Gasket, Cover	1
9		Button	2
10		Drive	1
11		Pump Rotor/Ball (S/A)	1
		Pump Rotor/Ball/Pin (S/A)	1
12		Cam Ring (S/A)	1
13		Insert	1
14		Control Shaft, External Thrd.	1
15		Housing (S/A)	1
16		Screw, 1/4-20 Hex Flange	5
17		Cover, Valve	1
18	1764020	Filter (Internal)	1
19	1764021	Gasket	1
20		Dump Valve Parts	1
21		Nut, Dump Valve Fitting	1
22		Seal, O-ring	1
23		Spring, Dump Valve	1
24	1757376	Bracket, Dump Valve	1
25	1757377	Seal, O-ring	1
26		Screw 5/16 Hex Flange	16
27		Gasket Axle Housing	2
28		18T Motor Rotor/Ball (S/A)	2
29		Pad, Friction (S/A)	2
30		Plate, Reaction	2
31		Plate, Backup	2
32		18T Sun Gear First	2
33		Gear, Ring 54T	4
		Gear, Ring 57T	4

Ref #	Part #	Description	Qty.
34		18T Planet Gear (S/A) First	6
35		18T Primary Carrier (S/A)	2
36		18T Sun Gear, Second	2
37		18T Plnt Gear (S/A) Second	6
38		Secondary Carrier (S/A)	2
39		Axle Housing (S/A) A-Side	1
39a		Axle Housing (S/A) B-Side	1
		Magnet (S/A)	2
40		Housing, Axle	2
41		Ring, Retaining, External	4
42		Thrust Washer	4
43		Ring, Retaining, Internal	2
44	1757700	Bearing, Ball	2
45		Seal, Radial Lip	2
46		Shaft, Axle—A-Side	1
		Shaft, Axle—B-Side	1
48		375 Str. Fitting/O-ring (S/A)	A/R
53		Piston, Dampening	
		Piston (S/A)	2
		Piston (S/A)	2
54		Brake Lever Parts:	
A		Quad Seal	2
B		Rod, Push	2
C		E-Ring	4
D		Spring Base (S/A)	2
E		Spring, Conical	2
F		Shaft, Brake	1
G		Screw, Cap, Hex	1
H		Lever, Brake RH	1
I		Lever, Brake LH	1
J		Shim	A/R
K		Nut, Hex, Lock	13

MODELS 13064, 13065 & 13066

S/N 130640100101-130640199999
S/N 130650100101-130650199999
S/N 130660100101-130660199999

ITEM CODE	
1	Magneto
2	Alternator
3	Fuel Solenoid
4	Headlights
5	Attachment Clutch
7	Starter
10	Connector
11	Battery
12	Fuse
13	Start Solenoid
14	Seat Switch
15	Brake Switch
17	Key Switch
18	Light Switch
19	Attachment Switch
20	Attachment Light
21	Start Light
22	Voltage Sensor
23	Voltage Sensor Light
29	Accessory Socket
30	Accessory Plug
31	Cruise Light
32	Cruise Switch
33	Cruise Relay
34	Cruise/Brake Switch
35	Cruise Magnet









1753862
Engine Harness



1758466
Engine Harness



WIRE COLOR CODE	
B	Black
BL	Blue
O	Orange
P	Purple
R	Red
W	White
Y	Yellow
GN	Green
BR	Brown
GR	Gray
R/W	Red/White
R/B	Red/Black
R/Y	Red/Yellow
W/B	White/Black