


# Exploded Views and Parts List

## EXPLODED VIEW AND PARTS LIST — MAIN UNIT



Item	Part #	Description	Item	Part #	Description
1	P190156GS	BASE	10	I92199GS	ASSY, Extension
2	P187602GS	HANDLE	11	B1862BGS	GUN
3	I87606GS	BILLBOARD	12	I90668GS	KIT, Handle Fasteners
4	I90249GS	HOSE	13	I92553GS	KIT, Vibration Mount
5	I92134GS	KIT, Engine Mounting Hardware	14	I92526GS	KIT, Wheel
6	I92131GS	KIT, Pump Mounting Hardware	15	23139DGS	KEY
7	I94298GS	VALVE, Thermal Relief	16	I94106GS	ASSY, Pump (see page 3)
8	I94062GS	PUSHNUT	900	NSP	ENGINE
9	B4150GS	KIT, Spray Tips			

### Items Not Illustrated:

Part #	Description
I94615GS	MANUAL, Owner's
I94668GS	KIT, Decals
BB3061BGS	OIL, Engine

