

BOLENS 11 HP TRACTOR




Figure 1. TRIM ASSEMBLY

REF. NO	PART NO	DESCRIPTION	NO. REQ'D.	REF. NO	PART NO	DESCRIPTION	NO. REQ'D.
1	1725480	Hood & Grill	1	39	1185456	Nut, Tinnerman	2
2	1733029	Seat	1	40	1714642	Brace	2
3	● 1186098	Carriage Bolt, 5/16-18 x 3/4	1	41	1727469	Decal, PTO.	1
4	● 1100779	Hex Hd. Screw, 5/16-18 x 1-1/2	2	42	1713483	Foot Rest	2
5	1735265	Pivot Block	2	43	1713474	Spacer, Foot Rest	2
6	1732472	Retainer	2	44	● 1100243	Lockwasher, 3/8	6
7	1717262	Lens	2	45	● 1111614	Hex Hd. Capscrew, 3/8-16 x 3	4
8	1735630	Decal (Trademark).	1	46	● 1186231	Hex Nut, 3/8-16	4
9	1735377	Hood Decal R.H.	1	47	1713397	Bar, Support.	1
10	1735376	Hood Decal L.H.	1	48	1721893	Support, Fender	1
11	1717246	Hinge	1	49	1725464	Panel, Rear.	1
12	1186327	Screw, Flange, 5/16-18 x 1/2.	6	50	1727413	Decal, Instructions.	1
13	1186391	Lock Nut, Flange, 5/16-18 .	3	51	1722016	Bracket, Fender Support. . .	2
14	● 1186067	Carriage Bolt, 1/4-20 x 1/2 .	1	52	● 1185872	Truss Head Screw, 5/16-18 x 5/8.	2
15	● 1186130	Carriage Bolt, 3/8-16 x 1-1/4	1	53	1185873	Nut, Speed "U" Type 5/16-18.	2
16	1100044	Hex Hd. Capscrew, 5/16-18 x 3/4.	14	54	1734393	Reinforcing Plate.	1
17	● 1186230	Hex Nut, 5/16-18	8	55	1725615	Reflector	2
18	1734115	Seat Support Assembly. . . .	1	56	1734534	Fender	1
19	1733960	Spring.	1	57	1731329	Heat Shield	1
20	1735125	Nut & Washer Assembly . . .	1	58	1718180	Plug, Button.	1
21	1734269	Knob	1	59	1722505	Plug, Hole	1
22	1727419	Decal, Instrument Panel . . .	1	60	● 1100241	Lockwasher, 1/4	1
23	1725637	Lanyard.	1	61	1186389	Flange Nut, 1/4-20	4
24	● 1100804	Capscrew, 1/4-20 x 1/2. . . .	1	62	1717599	Pad, Rubber.	1
25	1100068	Hex Hd. Capscrew, 3/8-16 x 3/4	2	63	1110106	Nut, Self Locking	1
26	1735275	Heat Shield	1	64	1727417	Decal, Shift Inst.	1
27	● 1100242	Lockwasher, 5/16	12	65	1735517	Seat Stand	1
28	1733054	Panel, Instrument	1	66	1735110	PTO Lever Quadrant	1
29	● 1107382	Flat Washer, 5/16	4	67	1735115	Shield	1
30	● 1110107	Self Locking Nut, 5/16-18. .	3	68	1185211	Thd. Cutting Screw, 1/4-20 x 1/2	2
31	1177548	Shakeproof Washer, 5/16 . .	1	69	● 1187612	Lockwasher, 1/4	2
32	1735631	Decal, Fender.	1	70	1735111	Bushing.	1
33	1727127	Latch	2	71	● 1186229	Hex Nut, 1/4-20	1
34	1727126	Clip	2	72	1734515	Actuator Bracket.	1
35	1728772	Pop Rivet, 3/16.	2	73	121900	Bowed Washer	1
36	● 1100256	Flat Washer, 3/8	1	74	1735054	Handle Grip	1
37	● 1107381	Flat Washer, 1/4	2	NI	1735223	Spray Paint, White	
38	● 1115931	Phil Rec. Hd. Screw, 1/4-20 x 5/8	2	NI	1735222	Spray Paint, Black	

● Common Hardware - Purchase Locally (Grade 5 where applicable).

BOLENS 11 HP TRACTOR




Figure 2. ENGINE and DRIVE ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.	REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
1	1723413	Strap, Gas Tank	2	46	1714132	Crutch Tip	2
2	1723473	Cap, Gas Tank	1	47	1733061	Pulley	1
3	1735062	Tank, Gasoline (Incl. Ref. No. 2).	1	48	1735876	Rubber Trim	1
4	1718185	Clamp, Hose.	4	49	• 1185775	Capscrew, 3/8-16 x 2-3/4 . .	4
5	1731901	Valve, Shut-Off.	1	50	1104436	Woodruff Key, 3/16 x 3/4. .	1
6	1723519	Fuel Line.	1	51	1185224	Seal, Oil.	1
7	1731399	Filter, Fuel Line	1	52	1185976	Grease Fitting.	1
8	1717340	Belt Guide Assembly	1	53	• 1100043	Hex. Hd. Capscrew, 3/8-16 x 1-1/4.	3
9	• 1103470	Setscrew, 5/16-18 x 1/2 . . .	2	54	• 1107383	Flat Washer, 3/8	7
10	1713790	Spacer.	1	55	1713670	Shaft Coupling	1
11	• 1186230	Hex Nut, 5/16-18	23	56	• 1110107	Lock Nut, 5/16-18.	4
12	1725616	Belt Guide Bracket	1	57	• 1110818	Knurled Socket Head Capscrew, 5/16-18 x 3/4 . .	4
13	1717339	Belt Guide Rod.	1	58	1716561	Bonded Coupling.	1
14	• 1100242	Lockwasher, 5/16	15	59	1713794	Brake Drum	1
15	• 1100004	Hex Hd. Screw 5/16-24 x 3/4	2	60	1717343	Drive Shaft.	1
16	1735387	Spacer.	2	61	1800417	Lock Collar	1
17	*	Briggs & Stratton, 252417. .	1	62	1800418	Bearing Flange	2
18	• 1100779	Hex Hd. Screw, 5/16-18 x 1-3/4.	4	63	1733137	Bearing Only	1
19	• 1107382	Flat Washer 5/16.	4	64	1713395	Bearing Support	1
20	1114748	Mach Screw No. 10-32 x 1/2	1	65	1713686	Bracket	1
21	1187474	Square Key, 1/4 x 2-1/4 . . .	1	66	1731340	Sheave, A-belt.	1
22	1733090	Sheave, Engine	1	67	• 1186098	Carriage Bolt, 5/16-18 x 3/4	9
23	1731976	Elbow, 45°	1	68	1100277	Woodruff Key, 3/16 x 7/8. .	1
24	1721036	Lock Nut, Hex 1 NPT	1	69	• 1182554	Setscrew, 5/16-18 x 5/16 . .	2
25	1731391	Exhaust Pipe	1	70	1733439	Belt Drive 35"	1
26	• 1100240	Lockwasher No. 10	1	71	1725603	Belt, PTO.	1
27	1733065	Brake Band Assy.	1	72	1736160	"U" Bolt	2
28	• 1186259	Jam Nut 3/8-16.	2	73	1723130	Clamp, Saddle.	1
29	• 1100049	Hex Hd. Screw, 3/8-16 x 2-1/4.	1	74	• 1100242	Lockwasher, 5/16	6
30	1733062	Brake Support	1	75	• 1716369	Cotter Pin, Special.	1
31	• 1100045	Hex Hd. Screw, 5/16-18 x 1	2	76	1731973	Muffler	1
32	1731452	Cable Support Bracket	1	77	1723054	Shield Assy., Muffler	1
33	1713394	Plate Cover.	1	78	• 1100044	Hex Hd. Capscrew, 5/16-18 x 3/4	2
34	• 1111614	Hex Hd. Capscrew, 3/8-16 x 3	2	79	• 1731326	Support Assy., Engine Mounting	2
35	• 1100243	Lockwasher, 3/8	7	80	1103995	Lockwasher, 3/8 Tooth . . .	4
36	1118730	Ring, Retaining.	1	81	1724404	Support Assy., Muffler . . .	1
37	1185649	Ring, Retaining.	2	82	• 1110644	Capscrew, 3/8-16 x 3-1/4 . .	2
38	1721590	Washer-Seal	1	83	• 1107383	Flat Washer, 3/8	2
39	1185605	Bearing, Ball	1	84	1713789	Belt Guide	1
40	1715785	Support, PTO	1	85	1713788	Belt Guide	1
41	1185010	Bearing, Needle.	1	86	1715008	Universal Joint	1
42	1721589	Shaft, PTO	1				
43	1731392	Fuel Line.	1				
44	• 1103437	Setscrew, 1/4-20 x 1/4 . . .	2				
45	1723474	Clamp, Hose.	1				

*Order Parts from your Briggs & Stratton Outlet.

• Common Hardware - purchase locally (Grade 5 where applicable)




Figure 3. TRANSMISSION ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.	REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
1	• 1100352	Cotter Pin, 1/8 x 1-1/2	2	47	1185232	Drive Pin, 3/16 x 1-1/4	1
2	• 1120129	Hex Nut, 1-14	2	48	1713419	Shaft	1
3	1709578	Washer "D" Hole	1	49	1185360	O-Ring	1
4	1711786	Thrust Bearing	3	50	1707546	Flat Washer	2
5	1185295	Oil Seal	2	51	1185113	Bronze Bearing	1
6	1722132	Wheel Hub	1	52	1713412	Gear-38 T	1
7	1714558	Shim-.020	As Req.	53	1716741	Flat Washer	1
8	1714559	Shim-.005	As Req.	54	1185646	Bearing	2
9	1713457	Drive Pin	2	55	1716694	Free Wheeling Hub	1
10	1714557	Thrust Bearing	1	56	1703053	Sq. Key, 1/4 x 2-3/4	1
11	• 1100242	Lockwasher, 5/16	18	57	1715725	Drive Collar	1
12	• 1100078	Capscrew, 5/16-18 x 7/8	8	58	1185409	Drive Pin, 1/4 x 5/8	1
13	1110181	Dowel Pin	1	59	1713426	Lock Pin	1
14	1185232	Drive Pin, 3/16 x 1-1/4	1	60	1185590	Hitch Pin	1
15	1723558	Shifter Lever	1	61	1722140	Rear Axle	1
16	1723559	Handle Grip	1	62	1105678	Pipe Plug	2
17	• 1111599	Capscrew, 1/4-20 x 5/8	2	63	1712763	Washer	As Req.
18	1713455	Bearing Retainer	2	64	1177567	Retaining Ring	2
19	1722004	Pivot Ball	1	65	1713467	Pinion Shaft	2
20	1734540	Cover Plate	1	66	1713411	Worm Wheel	1
21	• 1100241	Lockwasher, 1/4	2	67	1714917	Bevel Gear-22 T	2
22	• 1186229	Hex Nut, 1/4-20	2	68	1714566	Drive Hub	1
23	182682	Breather	1	69	1104337	Sq. Key, 1/4 x 1-1/2	1
24	1713424	Shifter Shaft	2	70	1185300	Bronze Bearing	1
25	1177625	Drive Pin, 1/8 x 3/4	2	71	1713427	Gasket	1
26	1177388	O-Ring	2	72	1713428	Cover	1
27	1704692	Roll Pin, 1/8 x 1	3	73	• 1103195	Capscrew, 5/16-18 x 5/8	6
28	1713422	Connector	2	74	1713466	Bevel Pinion-10 T	2
29	1716489	Shifter Arm	2	75	1714565	Coupling	1
30	1185276	Bearing Cup	2	76	1714571	Bronze Bearing	1
31	1185275	Bearing Cone	2	77	1185426	Oil Seal	1
32	1713408	Worm Shaft	1	78	• 1100045	Capscrew, 5/16-18 x 1	4
33	1713597	Brake Drum	1	79	1714290	Bearing Retainer	1
34	1891820	Oil Seal	1	80	1714291	Shim-.010	As Req.
35	1185165	Needle Bearing	1	81	1714292	Shim-.003	As Req.
36	1713409	Gear-38T	1	82	1185572	O-Ring	1
37	1713439	Sliding Gear	1	83	1718067	Stud	2
38	1185280	Needle Bearing	1	84	1120209	Drive Pin, 3/16 x 3/4	1
39	1113527	Retaining Ring	1	85	1713465	Gear Case	1
40	1713436	Gear and Shaft	1	86	• 1185342	Set Screw, 5/16-18 x 3/8	1
41	1108841	Sq. Key, 3/16 x 1-1/2	1	87	1713421	Pin	1
42	1713442	Shaft	1	88	1713417	Spring	1
43	1104440	Ball Bearing	1	89	1713416	Ball, 1/4 dia.	2
44	1118809	Retaining Ring	2	90	1713429	Gasket	1
45	1187439	Retaining Ring	1				
46	1185352	Oil Seal	1	NI	1700182	Gear Lube	

• Common Hardware - purchase locally (Grade 5 where applicable)

BOLENS 11 HP TRACTOR




Figure 4. HAND CONTROLS and LIFT ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.	REF. NO	PART NO	DESCRIPTION	NO. REQ'D.
1	1730699	Control, Choke	1	28	1723379	Handle, PTO Control	1
2	1724527	Knob Only	2	29	1725523	Grip, Plastic	1
3	1890234	Shim	1-3	30	1177625	Pin, Drive	1
4	• 1185985	Nut w/Lockwasher (Keps) No. 10-24	4	31	• 1100346	Pin, Cotter 3/32 x 3/4	3
5	1730700	Control, Throttle	1	32	• 1107383	Flat Washer, 3/8	4
6	• 1100086	Hex Hd. Capscrew, 3/8-16 x 2-1/4	1	33	1723367	Spring, Compression	1
7	1713803	Idler Pulley	1	34	1723380	Pivot Assembly, PTO	1
8	• 1110108	Lock Nut, 3/8-16	1	35	1723381	Support, PTO Control	1
9	1704692	Pin, Drive 1/8 x 1	3	36	1714243	Bushing, Nylon	2
10	1732770	Shaft Assy., PTO Control . .	1	37	1185257	Ring, Retaining	2
11	• 1185147	Cotter Pin	2	38	• 1107382	Flat Washer, 5/16	2
12	1733066	Control Rod	1	39	• 1186230	Hex Nut, 5/16-18	2
13	• 1110106	Lock Nut 1/4-20	2	40	• 1100067	Hex Hd. Capscrew, 1/2-13 x 2	1
14	1705905	Bowed Washer 5/16	1	41	1714575	Lift, Tool	1
15	1185647	Bearing, Nylon	2	42	• 1185496	Nut, Self Locking Jam 1/2-13	1
16	1716590	Support Shaft	1	43	1703011	Spring, Pin	1
17	• 1100044	Hex Hd. Capscrew, 5/16-18 x 3/4	4	44	1714645	Rod	1
18	• 1100242	Lockwasher, 5/16	4	45	1714577	Handle, Tool	1
19	1185586	Nylined Bearings	2	46	1713075	Spring, Compression	1
20	1731955	Clutch Control Arm Assy . .	1	47	1715575	Grip, Tool Lift	1
21	1706782	Washer, Bowed	1	48	1714644	Plunger, Tool Lift	1
22	1723370	Pivot, PTO Control	1	49	• 1116287	Screw, Oval Hd. Phil. Rec., No. 10-24 x 5/8	4
23	1120210	Pin, Roll 3/16 x 1	1	50	• 1100043	Hex Hd. Screw, 3/8-16 x 1-1/4	4
24	1726632	Spring, Torsion	1	51	• 1186231	Hex Nut 3/8-16	4
25	1185892	Pin, Drive 1/8 x 1	1	52	• 1100243	Lockwasher 3/8	4
26	1891696	Pin, Drive 5/16 x 1-1/2 . . .	1				
27	1723368	Block, Pivot	1				

• Common Hardware - purchase locally (Grade 5 where applicable)




Figure 5. BRAKE and CLUTCH CONTROL ASSEMBLIES

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.	REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
1	• 1705092	Flat Washer	2	30	1733577	Interlock Switch	1
2	1185582	Bearing, Sleeve	1	31	1725473	Bracket, Interlock Switch . .	1
3	• 1186229	Hex Nut, 1/4-20	2	32	• 1103997	Ext. Lockwasher 1/2	1
4	• 1100241	Lockwasher, 1/4	2	33	1714840	Shaft, Cross	1
5	• 1100806	Hex Hd. Capscrew, 1/4-20 x 1	2	34	• 1100350	Pin, Cotter 1/8 x 1	2
6	1717372	Pedal, Clutch	1	35	1726130	Control Knob	1
7	1717267	Lug.	1	36	1716717	Parking Brake Rod	1
8	1716778	Spacer.	1	37	1177625	Pin, Drive 1/8 x 3/4	3
9	1717362	Clutch Rod	1	38	1716718	Parking Brake Stop	1
10	• 1100346	Pin, Cotter 3/32 x 3/4	6	39	1716716	Spring Bracket Assembly . .	1
11	1733963	Ball Joint.	1	40	1725933	Torsion Spring	1
12	• 1100243	Lockwasher, 3/8	1	41	1713772	Bracket, Brake Rod	2
13	• 1186212	Nut, 3/8-24	1	42	1735419	Brake Rod Assembly	1
14	• 1100770	Capscrew, 3/8-16 x 2-3/4 . .	1	43	1713780	Brake Shoe Assembly.	1
15	• 1110108	Lock Nut, 3/8-16	2	44	1713782	Compression Spring	1
16	1713802	Idler Pulley	1	45	1713806	Brake Shoe Rod	1
17	1713783	Spacer.	1	46	1713760	Brake Shoe Assembly.	1
18	1713804	Pivot Block	1	47	• 1111609	Hex Hd. Capscrew, 5/16-18 x 2-3/4	1
19	• 1107383	Flat Washer, 3/8	7	48	1713793	Brake Bracket.	1
20	1177548	Shakeproof Washer	1	49	• 1111608	Hex Hd. Capscrew, 5/16-18 x 2-1/2	2
21	1713795	Brake Rod	1	50	• 1100242	Flat Washer	2
22	• 1186230	Hex Nut, 5/16-18	4	51	1186393	Flange Nut 3/8-16	1
23	1185257	Retaining Ring	1	52	1716724	Extension Spring.	1
24	• 1110107	Lock Nut 5/16-18	3	53	• 1100770	Hex Screw 3/8-16 x 2-3/4 . .	1
25	• 1107382	Flat Washer, 5/16	2	54	1890234	Flat Washer	1
26	1713781	Compression Spring	1	55	1713804	Pivot Block	1
27	1727694	Brake Control Pivot	1	56	• 1177548	Shakeproof Washer	1
28	1725474	Activator	1				
29	1713390	Spring	1				

• Common Hardware - purchase locally (Grade 5 where applicable)

BOLENS 11 HP TRACTOR




Figure 6. FRAME, STEERING and AXLE ASSEMBLIES

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.	REF. NO	PART NO	DESCRIPTION	NO. REQ'D.
1	1727284	Steering Wheel	1	34	1708012	Flat Washer	1
2	1717263	Bearing	1	35	1715789	Wheel (Incl. Ref. No. 4) . . .	2
3	1717258	Support, Steering	1	36	1727902	Tubeless Tire 4.80/400 x 8 (Carlisle)	2
4	1185976	Grease Fitting	3			Tubeless Tire 4.80/400 x 8 (Goodyear Softrac)	2
5	1725466	Steering Shaft	1	37	1185615	Bearing, Ball	2
6	• 1100243	Lockwasher, 3/8	4	38	1185348	Roll Pin, 1/4 x 1-1/4	2
7	• 1107383	Flat Washer, 3/8	4	39	1185284	Drive Pin 1/4 x 2	1
8	• 1186231	Hex Nut, 3/8-16	4	40	1705092	Flat Washer	1
9	• 1100043	Hex Hd. Capscrew, 3/8-16 x 1-1/4	4	41	1713809	Steering Gear	1
10	1185279	Pin, Drive 1/4 x 2-1/4	1	42	1715899	Dust Cap, 1-1/2 ID	2
11	• 1100770	Hex Hd. Capscrew, 3/8-16 x 2-3/4	4	43	1715787	Wheel Only	2
12	• 1110108	Lock Nut, 3/8-16	4	44	1727901	Tubeless Tire 23 x 8.50-12 (Carlisle)	2
13	1723711	Plate, Reinforcement	4			Tubeless Tire 23 x 8.50-12 (Goodyear Softrac)	2
14	1185232	Pin, Drive 3/16 x 1-1/4	2	45	1718086	Valve Assembly	4
15	1717270	Support, Axle	1	46	1700821	Washer, Thrust	6
16	1713383	Pivot, Axle	1	47	1727899	Wheel Assembly	2
17	1713361	Ball Joint	2	48	1727900	Wheel Assembly	2
18	• 1186214	Nut, Hex Lock 1/2-20	1	49	1716563	Steering Arm	1
19	1713385	Rod, Tie	1	50	101085	Bolt, Hub	10
20	1723355	Tie Rod Arm Assy. R.H.	1	51	1714101	Hitch	1
21	1891696	Pin, Drive 5/16 x 1-1/2	2	52	• 1100245	Lockwasher, 1/2	2
22	• 1110152	Self Locking Nut, 1/2-20	4	53	• 1186233	Hex Nut, 1/2-13	2
23	1185976	Grease Fitting	2	54	1713811	Pinion, Steering	1
24	1723343	Axle, Front	1	55	1731869	Cap, Mounting	4
25	1723354	Tie Rod Arm Assy. L.H.	1	56	• 1100047	Hex Hd. Capscrew, 3/8-16 x 1-1/2	8
26	1717315	Plate Assy., Mounting	1	57	1185558	Bearing, Sleeve	2
27	• 1103995	Shake Proof Washer	8				
28	1722014	Frame Tube	1				
29	1722015	Frame Tube	1				
30	1723346	Spindle Assy. L.H.	1				
31	1717462	Drag Link	1				
32	1723345	Spindle Assy. R.H.	1				
33	1185616	Bearing, Ball w/Seal	2				
				NI	1723284	Grease Gun	
				NI	1723479	Multi-purpose Grease	

• Common Hardware - purchase locally (Grade 5 where applicable)

BOLENS 11 HP TRACTOR






Figure 7. ELECTRICAL SYSTEM

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.	REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
1	1185456	Tinnerman Nut	2	17	1734472	Seal	1
2	1185893	Speed Nut 1/4-20	2	18	1727326	Key Only	1
3 ●	1115931	Phil. Hd. Screw, 1/4-20 x 5/8	4	19	1735417	Wiring, Harness	1
4	1729547	Solenoid	1	20	1721252	Clip, U	2
5	1722113	Lead (Starter to Sol)	1	21	1732436	Interlock Switch - Short Contact Lever	1
6	1722081	Lead (Grd to Batt)	1	22	1728199	Interlock Switch - Long Contact Lever	1
7	1734364	Terminal Boot	1	23	1729478	Screw, THD Cutting No. 4- 40 x 1-1/4	2
8	1722430	Battery 12v-24 amp	1	24	1727777	Speed Nut No. 4-40	1
9	1722086	Carrier Battery	1	25	1734613	Ground Lead	1
10	1709652	Wing Nut, 1/4-20	2	26	1722731	Lead Wire (Sol to Batt.)	1
11	1805527	Battery Retainer	1	27 ●	1107382	Flat Washer 5/16	2
12	1722104	Clamp Rod	2	28	1733577	Interlock Switch	1
13 ●	1185872	Screw, 5/16-18 x 1/2	4	29 ●	1111599	Hex Screw 1/4-20 x 5/8	2
14	1185873	Speed Nut "U" Type, 5/16-18	4	30 ●	1110106	Lock Nut 1/4-20	2
15	1720976	Fuse, 20 Amp	1	31	1735119	Seat Switch Lead	1
16	1734196	Ignition Switch (Incl. Ref. No. 18)	1	32	1734366	Seat Switch	1

● Common Hardware - purchase locally (Grade 5 where applicable)