




SECTION 1: PARTS LIST FOR MODELS 190-190-100 & 190-192-190



Components of Bag Assembly:



Components of Cover Assembly PN # 664-04018:



Model 190-190-100 & 190-192-190

Ref. No.	Part No.	Description
1.	17200A	Catcher Support Bracket
2.	17247	Tubing Adapter
3.	631-0221A	Chute Elbow
4.	664-04018	Cover Assembly (includes ref. 35 to 46)
5.	683-0617	Bracket Assembly: Chute Stop
6.	689-00002	Grass catcher Support Assembly
7.	710-0597	Hex Bolt 1/4-20 x 1.0
8.	710-0751	Hex Bolt 1/4-20 x 0.620
9.	710-3008	Hex Bolt 5/16-18 x 0.75
10.	710-3168	Carriage Bolt
11.	711-0309A	Clevis Pin
12.	711-04069	Grass catcher Pin
13.	712-0130	Hex Lock Nut 3/8-16
14.	712-0431	Flange Lock Nut 3/8-16
15.	712-3004A	Flange Lock Nut 5/16-18
16.	712-04064	Flange Lock Nut 1/4-20
17.	714-0117	Hairpin Clip
18.	723-04008A	Chute Strap
19.	723-0476	Chute Strap
20.	731-0926B	Catcher Tube
21.	749-0745A	Tube: Grass Bag Frame
22.	736-0253	Beleville Washer
23.	736-0270	Bell Washer
24.	736-3092	Flat Washer
25.	738-0380	Shoulder Screw
26.	742-04056C	Blade: High Lift; Star Hole
	742-04067C	Blade: High Lift; Round Hole
27.	783-0601	Catcher Support Bracket
28.	783-0673	Catcher Support Bracket RH
29.	783-0764	Catcher Support Bracket LH
30.	783-0765	Bracket: Cross Support
31.	783-1501	Spacer
32.	764-0251	Grassbag
33.	17202A	Screen Mounting Bracket
34.	710-1652	Screw 1/4-20 x 0.625
35.	720-04018	Screen
36.	726-04027	Push Nut
37.	726-0479	Ratchet Clip
38.	728-0123	Pop Rivet
39.	731-04166	Grass Bag Cover
40.	731-04189	Retainer Seal
41.	731-0824A	Plastic Plate
42.	735-04020	Grass Bag Seal
43.	736-0400	Flat Washer
44.	749-0747	Hinge Bracket
45.	17201A	Bag Hanger Bracket
46.	710-0473	Machine Screw
47.	710-0604A	TT Screw 5/16-18 x 0.625
48.	712-0272	Hex Sems Nut
49.	703-05783	50" Deck Deflector
50.	710-3015	Hex Head Screw 1/4-20