

MODEL 6877

**BOLENS
GRASS
HOPPER/BAGGER**

PARTS LIST

BOLENS GRASS HOPPER/BAGGER

MODEL 6877



REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
1	1728853	COVER	1
2	1185472	MACHINE SCREW, ... #10-24 x 1/2	13
3	1103959	FLAT WASHER, #10	13
4	1100240	LOCKWASHER, #10	13
5	1186227	HEX NUT, #10-24	13
6	1728854	STRAP	1
7	1728859	CHUTE - CENTER	1
8	1728864	CHUTE - LOWER	1
9	1729757	DECAL (WARNING)	2
10	1730315	BRACKET	1
11	1729665	BLADE - CUTTER	1
12	1728856	FRAME - GRASS BAG	1

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
13	1728592	GRASS BAG	1
14	1728862	FRAME ASSEMBLY.	1
15	1729689	DEFLECTOR	1
16	1186229	HEX NUT, 1/4 x 20	1
17	1100241	LOCKWASHER, 1/4	1
18	1728193	BRACKET - STOP	1
19	1100811	CAPSCREW, 1/4-20 x 1-1/2	1
20	1727342	CAP - PUSH ON	4
21	1724492	SCREW - FLANGE, ... 1/4-20 x 1/2	3
22	1729688	DECAL (INSTRUCTIONS)	1
23	1727379	POP RIVET, 3/16	4