




Bag Adapter Kit

Model 6883

ASSEMBLY

1. Loosen nuts fastening chute cover to mower deck and tip chute up. With chute (A) hooked in back of mower hole, fasten the front with quarter turn fastener on chute.
2. Install bag hanger (B) into hole in handle support of mower.
3. Fasten grass bag (C) to chute and slip loop of bag over bag hanger.
4. Position exhaust deflector (D) over muffler and fasten with screw (E) provided. Aim exhaust deflector down and to the rear.



REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D.
A	1894112	Chute	1
B	1723814	Bag Hanger	1
C	1731986	Grass Bag	1
D	1731454	Exhaust Deflector, 2 in. Diameter	1
E	1731453	Screw	1