


ILLUSTRATED PARTS LIST

**THREE POINT HITCH
MODEL 18010-01
MODEL 18010-02**



Ref. No.	Part No.	Description	No. Req'd
1	1100 245	Lockwasher 1/2	2
2	1107 038	Capscrew 1/2 - 13 x 2-1/2	2
3	1121 511	Hex Nut 1/2-13	2
4	1107 382	Flat Washer 5/16	2
5	1110 107	Locknut 5/16 x 18	2
6	1715 525	Pivot	2
7	1719 385	Lift Assembly - L.H.	1
8	1719 386	Lift Assembly - R.H.	1
9	1719 349	Retaining Pin	6
10	1719 387	Link Pin	2
11	1719 582	Chain Assembly	2
12	1718 773	Clevis Pin 3/4 x 2-3/4	2
13	1703 011	Spring Cotter	2
14	1185 743	Drive Pin 5/16 x 4	2
15	1719 367	Clevis Pin	2
16	1719 388	Adjusting Plate	2

Ref. No.	Part No.	Description	No. Req'd
17	1704 692	Drive Pin 1/8 x 1	2
18	1107 386	Flat Washer 5/8	4
19	1185 590	Hitch Pin	8
20	1719 372	Adjusting Nut	2
21	1719 391	Adjusting Shaft	2
22	1719 389	Cross Bar	1
23	1719 373	Shaft Pivot	2
24	1700 821	Thrust Washer	4
25	1120 210	Drive Pin 3/16 x 1	4
26	1719 580	Adj. Handle - Link Assy	1
27	1719 578	Stud - R.H.	1
28	1719 579	Stud - L.H.	1
29	1185 277	Drive Pin 1/4 x 3/4	2
30	135 035	Cotter Pin (10 GA)	2
31	1721 204	Sway Bar (Mod. 18010-02)	1



BOLENS

PORT WASHINGTON, WISCONSIN, U.S.A.

PRINTED IN U.S.A.

FORM NO. P-551958
REISSUED 3/68